

OSBORNE & LITTLE

READY-TRIMMED WALLPAPER

WIPEABLE SURFACE

ROLL SIZE: 10.05m x 52cms (20¹/₂ins x 11yds)

MADE IN ENGLAND

HANGING INSTRUCTIONS ARE OVERLEAF

REF: **W5226-03**

REPEAT: **72cm**

BATCH: **2504A**

IMPORTANT WALLPAPER HANGING INSTRUCTIONS

PLEASE READ CAREFULLY BEFORE HANGING THIS WALLPAPER

- 1. INSPECT EVERY ROLL** to ensure that all rolls have the same batch number and are in good condition, with no variations in shade, and that no other faults are present. The company cannot accept liability for defects which are apparent at the time of hanging, nor can the company be responsible for any consequential loss. Please retain all batch labels until decorating is completed. After hanging 2 or 3 lengths we strongly recommend that you carefully inspect the results.
No claim for hanging costs will be allowed for goods hung in excess of one roll.

2. PREPARATION:

- Walls should be clean, firm, dry and smooth.
- Roughen painted surfaces with glass/sandpaper.
- Remove any old wallpaper.
- Scrape powdery or flaky areas and paint with a suitably prepared size, allowing to dry completely.
- Cross line the walls using a good quality lining paper.

3. PASTING:

- Use a good quality adhesive containing a preservative and mix to manufacturer's instructions for medium to heavy weight papers.
- Apply an even coat of paste to the paper ensuring edges are well covered, but avoid getting paste on the surface.
- Allow a sufficient soaking time for the paper to become fully pliable (approximately 3-7 minutes).
- Care should be taken not to crease the paper when folding.

4. HANGING:

- Butt the joins and use a clean soft decorator's brush to smooth down paper, working from centre to edges of paper to remove bubbles.
- Avoid squeezing paste out of joins.
- **Any paste on the surface should be wiped off while it is still moist, using a clean damp sponge. Do not rub edges.**
- Dried paste could damage the surface of the wallpaper.
- Ensure wallpaper is firmly stuck down, as, in the event of fire, loose wallpaper could contribute to the hazard. For the same reason it is recommended that this wallpaper should not be applied over expanded polystyrene wall veneers.